

1750

1950

1950

2050

2150

2250

1400x1400

1500x1500

1600x1600

1700x1700

1800x1800

1900x1900

(C)



2020

2170

2320

2470

2620

2770

2920

Width


.

Height

. . . .


œ

Bidapro reserves the rigths to change dimensions at any time without prior notice







DIMENSIONS FROM 200X200 TO 2000X2000 BIDIRECTIONAL		
HOLE DIMENSIONS	А	В
200X200	380	545
300X300	480	745
400X400	580	945
500X500	680	1145
600X600	780	1345
700X700	880	1545
800X800	980	1745
900X900	1130	2016
1000X1000	1230	2216
1100X1100	1330	2416
1200X1200	1430	2616
1300X1300	1650	2916
1400X1400	1750	3116
1500X1500	1950	3316
1600X1600	1950	3530
1700X1700	2050	3730
1800X1800	2150	3980
1900X1900	2250	4180
2000x2000	2350	4458





Bidapro reserves the rigths to change dimensions at any time without prior notice







- · Using the orifices of the frame, drill the holes for expanding bolts;
- Now remove the penstock in order to apply the sealant model Sikaflex (or similar) to avoid leakages; • Then place again the penstock on the wall and tighten bolts, being careful near by the seat and making sure not to deform the frame:
- If the frame begin to deform due to unnoticed wall irregularities, stop tightening bolts. Remove the penstock, fill gaps with an appropriate grout, wait for the grout to become dry and then start again tightening;
- · Clean and grease the penstock for a open close test.
- · Bidapro is not responsible for a penstock not installed correctly.

Maintenance

- · Check the EPDM seat and change it in case of deterioration;
- · Check the high density plyethylene sliders are in good condition and change them in case of deterioration. Keep the screwed part of the stem (spindle) and the actuator clean.

Routine operations

- · Opening and closing:
- · to open: turn the handwheel anticlockwise;
- to close: turn the handwheel clockwise. Do not apply unnecesary force while closing the penstock.

Guiding supports installation

- Use guiding support holes as a guidance to drill the wall keeping in mind that you have to place one guiding support for each 2 meters of extension for CMC "rising stem" and one for each 3 meters of extension for CMC "non rising" models.
- · Then tighten the bolts.

